CLASSIC
ADDITIONS

For fitting advice
call 0193856717

1a. Remove seat base

1b. Remove door strip by pulling up carefully

2. Unscrew as shown

3. Remove rear part of headrest and remove centre glass.
4. To get to bolts disassemble headrest casing and remove from rollover

5. Remove all self tappers to remove side panels
6. Remove plastic surround from where the seatbelt comes out from the side panel- here you will find a screw please remove.

7. Drill holes as indicated

8. Repeat for opposite side

9. After drilling is complete re-assemble car.

10. Fit wind deflector- please note the plugs/pins will bend as they go in the locating bush.

These fitting instructions are supplied as a guide only. Classic Additions Ltd accept no responsibility or liability for any damages, injury or loss caused as a result of following these instructions. Your statutory rights are not affected.